

# MUD 50<sup>th</sup> Anniversary/NAS90 Hard Top Speaker Panel

## Fitting Instructions

To attach the top edge of the trim you can either use the double-sided 3M adhesive tape (shown in red) to the back of the trim/body capping or use the smaller self-tapping screws to screw into the body capping. It helps the double sided tape adhere if you can maintain some pressure to the trim by wedging something between the seat-back and the trim.



Use the larger of the self-tapping screws to fasten the bottom lip of the trim into place on the bodytub.

The edges of the speaker trim closest the rear door opening will require trimming to accommodate the fasteners for the door striker/hardtop and the switch for the rear interior light. How much trimming is required will vary between cars due to the variation in tolerances with Defender build. The plastic can easily be trimmed to shape using a hacksaw, Dremmel or Multi-Tool.



Note that on Station Wagon models fitted with the factory quarter window trims, the top edge of the speaker trim is fully concealed by the window trim so any trimming you do doesn't have to be exact.



To beef up the sound from the speakers we recommend sticking sound deadening material (e.g. Dynamat, etc) to the back of the speaker trims to add extra weight and rigidity to the speaker panel.

You can also add sound deadening material to back of the bodywork directly behind the speaker.

