

MUD PALS Rear Door Panel Fitting Instructions

Kit includes

1x PALS Panel

1x Screw Kit

1x Foam Strip (not included pre 2002 doors).



Please read all of the instructions before fitment.

- Position/centralise the panel on the rear door frame.
- Mark the positions of the fixings onto the door frame.
- Drill fixing holes into door frame with a 4.5mm drill.
- Peel off adhesive backing from insulating foam strip and attach to the outer edge of PALS panel. Foam Strip only applicable to Post 2001> doors.
- Place fixing screws within the plastic cup washers.
- Once fixings are screwed into place and tightened down, the black screw caps snap into place on top of the cup washers.
- We recommend attaching any MOLLE pouches to the panel before fixing it to the door.