



You'll notice on the camera loom there are a pair of thin white and a green loop wires.

The WHITE wire is the 'Flip Image' wire. Cutting the WHITE wire will flip the image from a reverse camera image to a forward facing camera image. The default camera image as supplied is a reverse camera image so this wire should be left intact.

The Green wire is for the Parking Lines. If you wish to remove parking lines from the image, cut the Green wire.

